

WD36SS-1 AND WD42SS-1 OPTIONAL DECORATIVE COVERS INSTALLATION INSTRUCTIONS

INSTRUCTIONS MUST BE LEFT WITH THE OWNER FOR FUTURE REFERENCE AFTER INSTALLATION.

1. Place (4) metal spacers over (4) #10 x 1" Hex head screws.
2. Place one screw and spacer in each hole in outer wrapper side opening, in four positions as shown in Figure 10.
3. Remove film from decorative cover.
4. Install decorative frame and door assembly on fireplace by aligning slots on frame with the (4) spacers installed at side openings. See Figure 10.

Note: Do not operate fireplace with decorative cover in place.

